

Replacement Handles

ACRYLIC KITCHEN/
LAVATORY HANDLE

- For Kohler
- Oval Style Broach
- 2 Handles & Screws and H/C Buttons



Part#	description	finish
21B1202	hot & cold (pair)	acrylic

TRI-BLADE HANDLE

- For Kohler
- 19 Point Broach
- Metal
- 2 Handles & Screws



Part#	description	finish
21B1213	hot & cold (pair)	CP

VOLUME CONTROL
KNOB

- For Mixet



Part#	description	finish
21B1222	smoke	acrylic
21B1228	clear	acrylic

VOLUME LEVER

- For Mixet
- Plastic



Part#	description	finish
21B1237	plastic volume lever	CP

VOLUME LEVER

- For Mixet Single Control Shower Valve
- Includes Insert & Screw
- Plastic



Part#	description	finish
21B1245	smoke	acrylic
21B1247	clear	acrylic

Replacement Handles

SINGLE CONTROL HANDLE

- For Moen



Part#	description	finish
21B1253	short socket-kit/lav	acrylic
21B1255	long socket-T&S	acrylic

SINGLE CONTROL HANDLE

- For Moen
- Oval



Part#	description	finish
21B1268	short socket-kit/lav	acrylic
21B1269	long socket-T&S	acrylic

FAUCET, TUB & SHOWER
HANDLE

- For Moen
- Includes 1 Handle, Hot & Cold Buttons and 2 Screws: 1 short for kit/lav. 1 long for T&S



Part#	description	finish
21B1275	handle set	acrylic

SINGLE LEVER HANDLE
OLD STYLE

- For Moen



Part#	description
21B1281	short socket & cap
21B1283	short socket-cap & handle
21B1298	handle only

SINGLE LEVER HANDLE
NEW STYLE

- For Moen Chateau



Part#	description
21B1291	long socket & cap
21B1298	handle only