

Replacement Buttons

ACRYLIC INDEX BUTTON
4 Arrow

- For Delta, Delex & Peerless



Part#	description	finish
21B1603	4 arrow index button	acrylic

ACRYLIC INDEX BUTTON
Wave

- For Delta, Delex & Peerless



Part#	description	finish
21B1612	wave index button	acrylic

ACRYLIC INDEX BUTTON
H/C - Gold

- For Delta, Delex, Peerless & EZ-FLO



Part#	description	finish
21B1623	H index button	acrylic
21B1625	C index button	acrylic

ACRYLIC INDEX BUTTON
Diamond

- For Gerber



Part#	description	finish
21B1635	H index button	acrylic
21B1637	C index button	acrylic
21B1639	diverter index button	acrylic

ACRYLIC INDEX BUTTON
H/C - Clear

- For Kohler



Part#	description	finish
21B1644	H index button	acrylic
21B1646	C index button	acrylic
21B1648	diverter index button	acrylic

ACRYLIC INDEX BUTTON
Round

- For Moen



Part#	description	finish
21B1679	round index button	acrylic

Replacement Buttons

ACRYLIC INDEX BUTTON
Oval

- For Moen



Part#	description	finish
21B1685	oval index button	acrylic

ACRYLIC INDEX BUTTON
H/C - Black

- For Moen



Part#	description	finish
21B1693	H index button	acrylic
21B1697	C index button	acrylic

ACRYLIC INDEX BUTTON
Chrome Plated

- For Price Pfister



Part#	description	finish
21B1655	H index button	CP
21B1656	C index button	CP
21B1657	diverter	CP

ACRYLIC INDEX BUTTON
Sunburst

- For Sayco & EZ-FLO



Part#	description	finish
21B1662	H index button	CP
21B1664	C index button	CP
21B1668	diverter	CP

ACRYLIC INDEX BUTTON
H/C

- For Valley



Part#	finish	description	finish
21B1703		H index button	acrylic